

## LOW PRESSURE TRANSDUCER

For Additional Information See PR-274/275 Data Sheet

### SPECIFICATIONS

**Accuracy\*:** ± 1% FS

**Overpressure:** 10 PSID

**Supply Voltage:** 12-40 VDC  
 12-35 VAC (VDC output units only)

**Supply Current:** VDC Units - 10 mA max.  
 mA Units - 20 mA max.

**Enclosure:** 18 Ga C. R. Steel NEMA 4 (IP-65) or Panel Mount Chassis

**Finish:** Baked on enamel-PMS2GR88B

**Compensated Temp Range:** 25°F-150°F (-4°C-65°C)

**T. C. Error:** ±0.0125%/°F (.02%/°C)

**Operating Temp Range:** 0°F-175°F (-18°C-80°C)

**Media Compatibility:** Clean dry air or any inert gas

**Environmental:** 10-90%RH Non-Condensing

**Termination:** Unpluggable screw terminal block

**Wire Size:** 12 Ga max.

**Load Impedance:** 1.6K ohms max. at 40 VDC (mA output units)  
 1K ohms min. (VDC output units)

**Weight:** Enclosure - 1.0 lbs. (.45 kg)  
 Panel Mount - 0.5 lbs. (.25 kg)


*\*Includes non-linearity, hysteresis and non-repeatability*

### ORDERING INFORMATION


PACKAGING	RANGE	OUTPUT
274 (enclosure)	R1 ("wc)	0 TO 0.10 / -0.05 TO +0.05 mA (4-20 mA 2-wire)
275 (panel mount)	R2 ("wc)	0 TO 1.0 / 0 TO 0.5 / 0 TO 0.25 / -0.5 TO +0.5 / -0.25 TO +0.25 / -0.125 TO +0.125
	R3 ("wc)	0 TO 5.0 / 0 TO 2.5 / 0 TO 1.25 / -2.5 TO +2.5 / -1.25 TO +1.25 / -0.625 TO +0.625
	R4 ("wc)	0 TO 30 / 0 TO 15 / 0 TO 7.5 / -15.0 TO +15.0 / -7.5 TO +7.5 / -3.75 TO + 3.75
	R5 (pa)	0 TO 25 / -12.5 TO +12.5
	R6 (pa)	0 TO 250 / 0 TO 125 / 0 TO 62.5 / -125 TO +125 / -62.5 TO +62.5 / -31.25 TO +31.25
	R7 (pa)	0 TO 1250 / 0 TO 625 / 0 TO 312.5 / -625 TO +625 / -312.5 TO +312.5 / -156.25 TO +156.25
	R8 (pa)	0 TO 7500 / 0 TO 3750 / 0 TO 1875 / -3750 TO +3750 / -1875 TO +1875 / -937.5 TO +937.5

### INSTALLATION

**Inspection** - Inspect the package for damage. If damaged, notify the appropriate carrier immediately. If undamaged, open the package and inspect the device for obvious damage. Return damaged products.



Enclosure Mount  
Transducer



Panel Mount  
Transducer

- Requirements**
- Tools (not provided)
    - Digital Volt-ohm Meter (DVM)
    - Appropriate screwdriver for mounting screws
    - Appropriate drill and drill bit for mounting screws
  - Appropriate accessories
  - Two #8 self-tapping mounting screws (*not provided*)
  - Training: **Installer must be a qualified, experienced technician**



**Warning:**

- Disconnect power supply before installation to prevent electrical shock and equipment damage.
- Make all connections in accordance with the job wiring diagram and in accordance with national and local electrical codes. Use copper conductors only.



**Caution:**

- Use electrostatic discharge precautions (e.g., use of wrist straps) during installation and wiring to prevent equipment damage.
- Avoid locations where severe shock or vibration, excessive moisture or corrosive fumes are present. NEMA Type 4 housings are intended for outdoor use primarily to provide a degree of protection against wind-blown dust, rain, and hose-directed water.
- Do not exceed ratings of the device.



**Caution:**

- Condensate or moisture must not enter pressure sensor ports

### Mounting

The PR-274/275 must be mounted as indicated by the arrows on the enclosure. Refer to **Figure 7** for mounting dimensions.

1. Remove the transducer cover using a Phillips head screwdriver.
2. Select the mounting location.
3. Mount transducer on a vertical surface with two #8 self-tapping screws (not provided).
4. Transducer must be mounted above the pressure pick-up or a J-Loop must be incorporated in the tubing to function as a condensate trap.
5. Pull wires through bottom of enclosure and make necessary connections.
6. Replace cover and make pneumatic connections.

### Wiring


Use maximum 12 AWG wire for wiring terminals. Use flexible 1/4" O.D. 5/32" I.D. tubing for the high and low pressure connections. Refer to **Figures 1, 2, 3, & 4** for wiring information and **Figures 5 & 6** for switch designations.

*(Wiring Instructions continued on pages 2 and 3.)*

**LOW PRESSURE TRANSDUCER**

**Wiring PR-274/275 Units with mA Output**

*PR-274/275 Low Pressure Transducer with mA Output*



PR-274/275 pressure transducers with 4-20 mA output are powered with a 12-40 VDC supply.


The following describes the proper wiring of these pressure transducers with mA output:

1. Remove the terminal block by carefully pulling it off the circuit board.
2. Locate the [+] and [-] terminal markings on the board.
3. Attach the supply voltage to the [+] lead.
4. Connect the 4-20 mA output ([-] terminal) to the controller's input terminal.
5. Ensure that the power supply common is attached to the common bus of the controller.
6. Re-insert the terminal block to the circuit board and apply power to the unit.
7. Check for the appropriate output signal using a DVM set on DC milliamps connected in series with the [-] terminal.


**TYPICAL APPLICATIONS (wiring diagrams)**

**Figure 1** and **Figure 2** illustrate typical wiring diagrams for the mA output low pressure transducer.

**Figure 1 - Wiring for mA Low Pressure Transducers with an External DC Power Supply**




**Figure 2 - Wiring for mA Output Transducers where the Controller or Meter has an Internal DC Power Supply**



**Wiring PR-274/275 Units with VDC Output**

*PR-274/275 Low Pressure Transducer with VDC Output*



PR-274/275 pressure transducers with VDC output are field selectable 0-5 VDC or 0-10 VDC output and can be powered with either a 12-40 VDC or 12-35 VAC.


The following describes the proper wiring of these pressure transducers with VDC output:

1. Remove the terminal block by carefully pulling it off the circuit board.
2. Locate the [+], [-] and [0] terminal markings on the board.
3. Attach the power wires to the [+] and [-] terminals. The [-] terminal is also the negative terminal.
4. Connect the [0] terminal, which is the positive VDC output terminal, to the controller's input terminal.
5. Re-insert the terminal block to the circuit board and apply power to the unit.
6. Check the appropriate VDC output using a voltmeter set on DC volts across the [0] and [-] terminals.


**TYPICAL APPLICATIONS (wiring diagrams)**

**Figure 3** and **Figure 4** illustrate typical wiring diagrams for the VDC output low pressure transducer.

**Figure 3 - Wiring for VDC Low Pressure Transducers When Applied with External AC Supply**



**Figure 4 - Wiring for VDC Low Pressure Transducers When Applied with External DC Supply**






RoHS

**LOW PRESSURE TRANSDUCER**

Figure 5 - Switch Selections for Low Pressure Transducers with mA Outputs



**Range Configuration: Uni-Directional Switch 1 (S1)**

R1/R5	0 - 0.10 "wc / 25 pa (default)	
R2/R6	0 - 1.0 "wc / 250 pa (default)	
	0 - 0.5 "wc / 125 pa	
	0 - 0.25 "wc / 62.5 pa	
R3/R7	0 - 5.0 "wc / 1250 pa (default)	
	0 - 2.5 "wc / 625 pa	
	0 - 1.25 "wc / 312.5 pa	
R4/R8	0 - 30.0 "wc / 7500 pa (default)	
	0 - 15.0 "wc / 3750 pa	
	0 - 7.5 "wc / 1875 pa	


**Range Configuration: Bi-Directional Switch 1 (S1)**

R1/R5	+/- 0.05 "wc / 12.5 pa (default)	
R2/R6	+/- 0.5 "wc / 125 pa (default)	
	+/- 0.25 "wc / 62.5 pa	
	+/- 0.125 "wc / 31.25 pa	
R3/R7	+/- 2.5 "wc / 625 pa (default)	
	+/- 1.25 "wc / 312.5 pa	
	+/- .625 "wc / 156.25 pa	
R4/R8	+/- 15.0 "wc / 3750 pa (default)	
	+/- 7.5 "wc / 1875 pa	
	+/- 3.75 "wc / 937.5 pa	

**Output Configuration: Switch 2 (S2)**

Uni-directional (default)	
Bi-directional	

Figure 6 - Switch Selections for Low Pressure Transducers with VDC Outputs



**Range Configuration: Uni-Directional Switch 1 (S1)**

R1/R5	0 - 0.10 "wc / 25 pa (default)	
R2/R6	0 - 1.0 "wc / 250 pa (default)	
	0 - 0.5 "wc / 125 pa	
	0 - 0.25 "wc / 62.5 pa	
R3/R7	0 - 5.0 "wc / 1250 pa (default)	
	0 - 2.5 "wc / 625 pa	
	0 - 1.25 "wc / 312.5 pa	
R4/R8	0 - 30.0 "wc / 7500 pa (default)	
	0 - 15.0 "wc / 3750 pa	
	0 - 7.5 "wc / 1875 pa	

**Range Configuration: Bi-Directional Switch 1 (S1)**

R1/R5	+/- 0.05 "wc / 12.5 pa (default)	
R2/R6	+/- 0.5 "wc / 125 pa (default)	
	+/- 0.25 "wc / 62.5 pa	
	+/- 0.125 "wc / 31.25 pa	
R3/R7	+/- 2.5 "wc / 625 pa (default)	
	+/- 1.25 "wc / 312.5 pa	
	+/- .625 "wc / 156.25 pa	
R4/R8	+/- 15.0 "wc / 3750 pa (default)	
	+/- 7.5 "wc / 1875 pa	
	+/- 3.75 "wc / 937.5 pa	

**Output Configuration: Switch 2 (S2)**

Uni-directional (default)	
Bi-directional	

**Output Configuration: Switch 3 (S3)**

0 - 10 (default)	
0 - 5 VDC	



**LOW PRESSURE TRANSDUCER**

- CHECKOUT**
1. Verify that the unit is mounted in the correct position.
  2. Verify appropriate input signal and supply voltage.

**Caution:** Never connect 120 VAC to these transducers. Never connect AC voltage to a unit intended for DC supply.

3. Verify appropriate configuration range.

**Transducer Operation** This is a rough functional check only.

1. Adjust the pressure to obtain maximum output signal for appropriate range.
2. Output should be 20 mA or 5 or 10 VDC.
3. Adjust the pressure to obtain minimum output signal.
4. Output should be 4 mA or 0 VDC.

**NOTE:** The PR-274/275 is a highly accurate device. For applications requiring a high degree of accuracy, the use of laboratory quality meters and gauges are recommended.

**CALIBRATION** All units are factory calibrated to meet or exceed published specifications. If field adjustment is necessary, follow the instructions below.

**Calibration of PR-274/275 mA Units**

1. Connect terminals [+] and [-] to the appropriate power source.
2. Connect the DVM in series on the [-] terminal.
3. Apply low pressure to the unit. If configured for uni-direction, adjust Zu trimmer to achieve desired low output. If configured for bi-direction, adjust Zb trimmer to achieve desired low output.
4. Apply high pressure to the unit and adjust span trimmer [S] to obtain the desired high output pressure.
5. Repeat steps 3 and 4 until desired calibration is achieved.

**Calibration of PR-274/275 VDC Units**


1. Connect terminals [+] and [-] to the appropriate power source. The [-] terminal is also the negative output terminal.
2. Connect the DVM on DC volts across [0] and [-] terminal.
3. Apply low pressure to the unit. If configured for uni-direction, adjust Zu trimmer to achieve desired low output. If configured for bi-direction, adjust Zb trimmer to achieve desired low output.
4. Apply high pressure to the unit and adjust span trimmer [S] to obtain the desired high output pressure.
5. Repeat steps 3 and 4 until desired calibration is achieved.

**MAINTENANCE** Regular maintenance of the total system is recommended to assure sustained optimum performance.



**FIELD REPAIR** None. Replace with a functional unit.

**WARRANTY** See Data Sheet for additional information.


**Figure 7 - PR-274/275 Low Pressure Transducer Dimensions shown in inches and millimeters (mm).**



**Panel Mount**



**Enclosure**



For Technical / Application Assistance call your nearest office



**8189 Century Boulevard • Minneapolis, MN 55317-8002 • USA**  
**800-843-5116 • 952-556-4900 • Fax 952-556-4997**  
**sales@mamacsys.com • www.mamacsys.com**

EUROPE
Baird House, Units 6 & 7 Dudley Innovation Centre Pensnett Estate • Kingswinford West Midlands • DY6 8XZ United Kingdom 01384-271113 • Fax 01384-271114

AUSTRALIA
4 Armingier Court, Unit 2 Holden Hill • S.A. 5088 Australia 08-8359-4333 • Fax 08-8395-4433

ASIA
No. 22 Lorong 21A Geylang #11-02 Prosper Industrial Building Singapore • 388421 656-3927273 • Fax 656-3927276

CANADA
155 McIntosh Drive, Unit 5 Markham • Ontario • L3R 0N6 Canada 905-474-9215 • Fax 905-474-0876

MAMAC Systems, Inc., reserves the right to change any specifications without notice to improve performance, reliability, or function of our products.